

GUÍA BUJÍAS MERCUISER

MODELO	CYL	SERIE	NGK	IRIDIUM	DENSO
233	8		NGK BPR6EFS	NGK TR6IX	TR20EPR-U
255	8	-4175498	NGK BR6FS	NGK BR6FIX	TR20R-U
255	8	4175499+	NGK BPR6EFS	NGK TR6IX	TR20EPR-U
888	8	4169597+	NGK BPR6EFS	NGK TR6IX	TR20EPR-U
330	8		NGK BR6ES		
390	8		NGK BR6ES		
420 , 440 CICLONE,454 MAG ALPHA	8		NGK BR6FS	NGK BR6FIX	TR20R-U
454 MAG BRAVO , 454 MAF EFI-MPI	8		NGK BR6FS	NGK BR6FIX	TR20R-U
502 MAG,502 MAG EFI-MP,MPI	8		NGK BR6FS	NGK BR6FIX	TR20R-U
7.4L ALPHA, 7.4L BRAVO	8		NGK BR6FS	NGK BR6FIX	TR20R-U
7.4L MPI (L29)	8		NGK BPR6EFS	NGK BR6FIX	TR20EPR-U
7.4LX EFI BRAVO, MPI BRAVO	8		NGK BR6FS	NGK BR6FIX	TR20R-U
7.4TR	8	OB771113-OC407646	NGK BR6FS	NGK BR6FIX	TR20R-U
HP425, HP450, HP465, HP500,502CID	8		NGK BR6FS	NGK BR6FIX	TR20R-U
8.1L, 8.1 SHO, 8.1S HORIZÓN(2000-06)	8		NGK TR55	NGK TR55IX	
8.1 SHO, 8.1 S HORIZÓN (2007+)	8			NGK IZFR7M	